

**AMENDMENT NO. 1 DECEMBER 2003
TO
IS 7641 : 1975 SPECIFICATION FOR
4-CHLORO-2-ANISIDINE**

(Page 3, clause 0.2, line 3) — Substitute 'It is also known as 4-Chloro-2-aminoanisole (Fast Red R Base)' for 'Fast Red R Base'.

(Page 3, clause 0.2, Structural Formula) — Insert the following below the structural formula:

'(CAS No. 93-50-5)'

(Page 4, Table 1) — Substitute the following for the existing Table:

Table 1 Requirements for 4-Chloro-2-Anisidine

Sl No.	Characteristic	Requirement	Method of Test, Ref to Clause No. of IS 5299 : 2001
(1)	(2)	(3)	(4)
i)	Crystallization point, °C	80.5	8
ii)	Purity by nitrite value, percent by mass, <i>Min</i>	98.5	15
iii)	Matter insoluble in methanol, percent by mass	0.2	11.3
iv)	Presence of impurities, <i>Max</i> 4-Chloro-2-nitro anisole	0.2	17.3 and A-1

(Page 5, clause 4.3) — Insert the following Annex after 4.3:

**'ANNEX A
(Table 1)**

**THIN LAYER CHROMATOGRAPHIC ANALYSIS FOR
DETERMINATION OF IMPURITIES**

A-1 GENERAL

Impurities are determined by thin layer chromatography. Reference may be made to 'IS 5299 : 2001 Methods of sampling and tests for dye intermediates' for details of TLC test method to be followed. However, necessary details of test conditions are given here for guidance only.

Amend No. 1 to IS 7641 : 1975

- | | | |
|---|---|--|
| 1. Product name | : | 4-Chloro-2-Anisidine |
| 2. Sample solution (on 100% basis) | : | 4% Solution acetone |
| 3. Application/sample volume for spotting | : | 5 μ l (for sample)
2 μ l and 4 μ l (for impurities) |
| 4. Standard | : | Reference standard |
| 5. Test substance for impurities | : | 4-Chloro-2-nitro Anisole
(0.05% Solution in acetone) |
| 6. Plate type | : | Silica gel G |
| 7. Eluent | : | Toluene |
| 8. Elution time | : | 1 h |
| 9. Temperature | : | 25 $\pm$ 5°C |
| 10. Detection spray | : | *SnCl ₂ + PBAB solution |
| 11. Evaluation | : | Semi quantitative |
| 12. Approx Rf value — Main band | : | 4-Chloro-2-Anisidine : Rf 0.7 |
| — Impurities | : | 4-Chloro-2-nitro Anisole : Rf 0.85 |

*SnCl₂ solution : 10 % solution in (1:1) water + 5N HCl

PBAB solution : P-Dimethylamino benzaldehyde 1% solution in (1:0.5:0.5)

Methanol : Water : 5 N HCl

(PCD 11)